


HEDRA - FACTORY SETTINGS

Hedra Preset 1 "Series Sequence" - 115 bpm [520 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 2 "Pitch Echo" - 115 bpm [520 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange TAP footswitch = half speed enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 3 "Micro Fall" - 462 bpm [130 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 4 "Micro Chorus" - 462 bpm [130 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 5 "Hard Tune Triplet" - 333 bpm [180 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 6 "Stereo Octave" - 231 bpm [260 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 7 "Carle Place Shred - 286 bpm [210 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 8 "Expression Steel" - 115 bpm [520 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 9 "Tick Tock" - 115 bpm [520 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel




Toe




Hedra Preset 10 "Layers" - 111 bpm [540 ms]

Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange TAP footswitch = half speed enabled. Orange BYPASS footswitch = Pitch control smoothing enabled. For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 11 "Expression Shift" - [0 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 12 "Pentatonic Correct" - 273 bpm [220 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 13 "Infinite Arcade" - 857 bpm [70 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 14 "Mirror Glide" - 231 bpm [260 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange TAP footswitch = half speed enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




HEDRA - FACTORY SETTINGS

Hedra Preset 15 "Bumble Trail" - 316 bpm [190 ms]


Note: Black pointers = top layer settings. Orange pointers = secondary layer settings.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe




Hedra Preset 16 "Folding Intervals" - 286 bpm [210 ms]

Note: Black pointers = top layer settings. Orange pointers = secondary layer settings. Orange BYPASS footswitch = Pitch control smoothing enabled.

For secondary controls only, hold ALT button [L LED button] while turning knob. Release ALT button when knob settings are done.

Heel



Toe

