DJ-G7


all models

T: Exp. TX range

J: X-band RPT activation

E: Wideband RX
Exp. TX
X-band rpt.

Side A



Cut this blue jumper below LCD.

DJ-G7 Mod: Turn off. Remove 6 screws on the rear case and 2 nuts below the SQ/VR knobs. Slide the front case upward to see the shown jumper-wire on the board. Cut it to remove. Reassemble and reset by turning on with Func key pressed. This mod activates wideband TX/RX and X-band repeat on E model, expands TX range on J model.

(Exp. TX 136-170; 420-470, NO EXP. avail. on 1.2GHz)